HOME DECORATORS
collection

Assembly Instructions

HDC#. 01443 MFG#. MD-014-BT

Please read over the instructions; it will be a time-saver in the long run.

Note: Before Assembly, please be sure to work on a soft flat surface to avoid any damage to the finish.



Step 1:Assemble seat(B) to back(A).
A:First use the bolt(D) and washer lock to attach the seat to the back through the middle hole.Tighten by hand,but keep loose.
B:Then assemble the seat and back using bolts(E) and washer lock,tightening by hand but **keeping loose.**



Step 2:Assemble front legs(C) to the bottom of seat using bolts(D) and washer lock.Tighten by hand,but **keep loose.**



Step 3:Place the chair in loose condition on flat surface(table top or floor),make sure the chair is level,then tighten **all the bolts using the Allen Key(H).Be careful not to overtighten,otherwise you may crack the legs!**

BACK(A)		1PC
SEAT(B)		1PC
FRONTLEGS(C)		2PCS
BOLT(D)	Ø6*50MM	5PCS
BOLT(E)	Ø8*90MM	4PCS
WASHER(F)		9PCS
LOCK(G)		9PCS
ALLEN KEY(H)		1PC